

Motion Record Setup Guide

You must be logged in as Admin

Note: First save your settings before copying settings to other cameras

Step 1:

Go to Main Menu // Record Settings // Manual
Uncheck 'ALL' or the camera number you want to enable motion on
This will turn off continuous recording
Select SAVE

*If you want to enable motion on other cameras you can now select copy
Once done Right Click to exit menu*

Step 2:

Go to Main Menu // Record Settings // Record Para.
Change Record Mode to motion
*Note – ALL is a default selection when entering or exiting this menu
Select SAVE

*If you want to enable motion on other cameras you can now select copy
Once done Right Click to exit menu*

Step 3:

Go to Main Menu // Motion Detection other Alarms // Motion
Select 'ALL' or camera number you have enabled motion on
Select desired sensitivity level (1=low 5=highest)
Click on Motion Area button to select your motion area
*By default the entire camera area is selected for motion
*Left click mouse to exit motion grid screen
Place a check in the box for ALL or the DAY motion recording should take place
*Left click and drag in the time bar to select exact times
Select SAVE
Right click to exit menu

Step 4:

When motion is detected you will hear an audible alarm to alert you of motion
This can be disabled or modified by going to:
Main Menu // Sensors and Alarms // Alarm Output
Uncheck Audio box and Buzzer Box
Select SAVE
Once done Right Click to exit menu